

## Installation of a front glass pane Morsø 5660

### Contents:

- Glass tape (2)
- 1 fitting (3)
- 2 M6 screws (4)
- 1 glass pane (5)
- 1 fitting (6)
- 2 M6x25 screws (8)

The handle (1) is removed from the door during the installation of the glass.

Fix the glass tape (2) to the back of the glass (5) along the sides at a distance of approximately 5 mm from the edge.

Attach the fitting (3) loosely to the underside of the door (7) with two M6 screws (4) supplied, and position the glass pane (5) between the fitting (3) and the stove door (7). Hold the glass pane firmly in place while the fitting (3) is tightened. Finally, fasten the other fitting (6) to the top of the stove door (7) with the M6x25 screws (8) supplied.

